Quick Start

Need more help? Go to **Apps > Device Help**

htc Desire 626

Camera Modes

Easily switch between different capture modes with a simple gesture. And even create custom camera modes.

ISO
EV
AWB
Expand controls
Convenient **Camera options** such as **Auto Selfie** and **Voice Selfie**
See all camera modes or add new ones
Swipe across the screen vertically in landscape orientation or horizontally in portrait orientation to switch camera modes.

HTC BlinkFeed®

Get your favorite topics, news, social media, and more conveniently delivered to one app on your phone.

1. From the Home screen, swipe right until you see HTC BlinkFeed.
2. In HTC BlinkFeed, swipe right to open the slideout menu.
3. Tap ⋮ > **Add content**.
4. Tap a category to see available content.
5. Select the content you want to add to the feed.

Turn off HTC BlinkFeed

1. From any Home screen, slide two fingers together.
2. Press and hold the HTC BlinkFeed thumbnail, then drag it to **Remove**.

Find More Information

Need More Help?

- On your phone: **Apps > Device Help**
- On the web: **att.com/DeviceHowTo**

Manage Your Account

- On your phone: **Apps > myAT&T**
- On the web: **att.com/MyATT**

Give us a Call

- 800.331.0500
- 611 from any AT&T wireless phone

Accessories

- **att.com/WirelessAccessories**

Coverage not available in all areas. Some features may require monthly access and/or per use charges. Visual and screen images are simulated. Contains Li-polymer battery - recycle or dispose properly. HTC, the HTC logo, HTC Desire, HTC BlinkFeed, and HTC Sense are trademarks or registered trademarks in the U.S. and/or other countries of HTC Corporation and its affiliates. LTE is a trademark of ETSI. 4G LTE not available everywhere. All other marks contained herein are property of their respective owners. © 2015 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property.

Printed in Taiwan P/N: 99HAAL000-00

HTC Sense® Home

Your home screen adapts to your life. At home, at work, and on the go. Apps automatically get added to the HTC Sense Home widget depending on where you used them.



Set or update your location

1. Tap ⌄ > ⋮ > **Set locations**.
2. Enter the addresses for your home and work locations.


HTC location services
Home
Link addresses or Wi-Fi networks
Work
Link addresses or Wi-Fi networks
By manually linking an address or Wi-Fi network with the home or work location, you agree to share your precise location and personal usage data with HTC Sense Home.

Tip: Optimize Battery Life

Switch to Power Saver or Extreme Power Saver Mode



Tap ⋮⋮⋮ > **Settings** > **Battery Manager**. Tap the **Power saver** or **Extreme power saving mode** switch to turn them on.

Note: Some features may be disabled in order to extend battery life. See the User Guide for details.

Activate Automatic brightness

1. Tap ⋮⋮⋮ > **Settings** > **Display & gestures** > **Brightness level**.
2. With the **Automatic brightness** option selected, set the limit for automatic brightness.

Check what apps are using your battery the most



1. Tap ⋮⋮⋮ > **Settings** > **Battery Manager** > **Battery usage**.
2. You can disable or uninstall apps that you don't use.

Note: Maximum standby and use time may vary depending on your current usage patterns, settings, and other factors and conditions.

Tip: Checking Connections



Having trouble connecting to the Internet? Try these steps:

1. Tap ⋮⋮⋮ > **Settings**.
2. If Airplane mode is on, tap the Airplane mode **On/Off** switch to reestablish your data connection.
3. Wi-Fi can provide additional data coverage. Tap the Wi-Fi **On/Off** switch to turn it on.
4. Mobile data enables 4G LTE service. Tap the Mobile data **On/Off** switch to turn it on.
5. Did you set a data limit and exceed it? Tap **More** > **Data Manager.** Clear the **Limit mobile data usage** option.
6. Open the browser and go to a website to test if your data connection is working.

AT&T Services

AT&T Ready2Go

Set up your email, social networking, Wi-Fi, and more.

AT&T DriveMode®

Stay safe while driving. Stops incoming calls and text.

AT&T Locker™

Cloud storage to store, sync, & share your photos, videos, and documents.

Keeper®

An easy-to-use app to manage and access your passwords and user names from your mobile devices and computers.

AT&T Navigator®

Get traffic updates, GPS navigation and turn-by-turn voice directions.

Mobile TV

Watch LIVE, on-demand and downloadable mobile TV including ESPN Mobile TV, Fox News, and more.

Data usage and subscription charges may apply.